VIBRATION CONTROL & SWAY BRACE

Fig. 296 Fig. 301: with Adjustable Preload Fig. C-296, Fig. C-301: Corrosion Resistant

Size Range: Preloads from 50 to 1,800 pounds and maximum forces from 200 to 7,200 pounds. Finish: Standard finish: painted with semi gloss primer. Corrosion resistant: galvanized with coated coil. Service: Recommended for controlling vibration; absorbing shock loading; guiding or restraining the movement of pipe resulting from thermal expansion; bracing a pipe line against sway.



Sway Brace

Approvals: Complies with Federal Specification A-A-1192A (Type 55)
WW-H-171E (Type 55), ANSI/MSS SP-69 and MSS SP-58 (Type 50).
Installation: Shipped ready for installation (see line cuts of Fig. 297, Fig. 298, Fig. 302 and Fig. 303 on page 211 for typical installed hanger assemblies).

Adjustment: The sway brace should be in the neutral position when the system is hot and operating, at which time both spring plates should be in contact with the end plates. If they are not, the sway brace should be adjusted to the neutral position by use of the load coupling.

Features:

- Vibration is dampened with an instantaneous opposing force bringing the pipe back to normal position.
- A single pre-loaded spring provides two way movement.
- One spring saves space and simplifies design.
- Spring has 3-inch travel in either direction.
- Accurate neutral adjustment assured.
- A tight fitting connection at rear bracket and clamp.

Additional Features – Fig. 301:

The Fig. 301 sway brace is adjustable from the initial preload to the maximum capacity of the unit selected. It is equipped with a load-deflection scale to facilitate preload adjustment. Preload adjustment reduces spring travel accordingly. **Ordering:** Specify figure, name and sway brace size. The Anvil Fig. 296 and Fig. 301 consist of the sway brace only. Available corrosion resistant as Fig. C-296 and Fig. C-301.

Preload adjustment – Fig. 301: Turn the preload adjustment nut until desired preload is indicated. Turn thrust nut until it is in contact with the spring plate. Lock in position. Indicated deflection must be greater than thermal movement.



www.anvilintl.com

IBRATION CONTROL & SWAY BRACE

Fig. 296, Fig. 301: with Adjustable Preload Fig. C-296, Fig. C-301: Corrosion Resistant

Sway Brace (cont.)

Straps

Pipe Supports

Trapeze

Pipe Shields & Saddles

Pipe Roll

Pipe Guides & Slides

Sway Brace Seismic

Spring Hangers

Constant Supports

/ibration Contro Brace

& Sway

Sway Strut Assembly

Snubbers

Special Design Products

Size selection: The Anvil Vibration Control and Sway Brace gives full deflection forces from 200 to 7,200 pounds and has initial precompressed spring forces from 50 to 1,800 pounds to control vibrations and pipe sway. The amount of force needed to control piping should be in proportion to the mass, amplitude of movement, and nature of disturbing forces acting on the pipe. When it is possible to calculate the exact restraining force required, the size of the Vibration Control and Sway Brace capable of providing this force should be selected. As a general reference, the following sizes have been historically used for the pipe sizes shown:

- #1 $3^{1}/_{2}$ " and smaller •
- #2 4" to 8"
- #3 10" to 16"
- #4 18" to 24"
- #5 and #6 above 24"





Installation: 1) attach rear bracket to structure and pipe attachment to piping or equipment. 2) connect coupling to pipe attachment and turn coupling so that spring is compressed in direction opposite to and by approximate amount of piping thermal movement.

Important: Final adjustment should be made with the pipe in its hot or operating position. Turn the coupling until both spring plates are in contact with the end plates of the Sway Brace. When correct tension adjustments are completed, the brace exerts no force on the pipe in its operating position. Under shutdown conditions, the brace allows the pipe to assume its cold position. It exerts a nominal cold strain force equal to the preload force plus the amount of travel from the hot to cold position, times the spring scale of the particular size of the Vibration Control and Sway Brace.



F

ig. 301	
I)	

FIG. 296: LOADS • WEIGHTS (LBS) • DIMENSIONS (IN)															
Sway Brace Size	Pipe	Preload and Spring Scale (lb/in)	Max Force (Ibs)	Weight	Rod Size Fig. 297 A	Eye		n	Length	v		D.A	N	Р	В
	Size					Dia. Hole	Thickness	U	F	ĸ	L	IVI	N		n
1		50	200	22	3/4	1	1	4 ½	13%	15⁄8	171/8		1	81/8	1¼
2	11/ to 04	150	600	25	1				14%		185/8	61/8		9 5⁄8	
3	3 1 1/2 10 24	450	1,800	36					17¾		22			13	
4		900	3,600	64	1¼	1½	1½	65%8	17	21⁄4	22 ⁵ /16	6¾	1½	11½	
5	6 to 20	1,350	5,400	79	1½				181/2		23 ¹³ ⁄16			13	1 ¹³ ⁄16
6	6 6 10 30	1,800	7,200	95					20 ¹ / ₂		25 ¹³ ⁄16			15	

6	6 to 30	1,800	7,200	95	I 1/2				201/2		25 ¹³ ⁄16			15		ation
														Applica Examp		
			FIG. 30	01: LOA	ADS • W	EIGHT	5 (LBS) •	DIM	ENSIC	DNS (IN)					
Sway Brace Size	Pipe	Preload and M Spring Scale F((lb/in) (l	Max	Weight	Rod Size	E	Eye		n Length	K		М	N	D	R	r Format t Specs.
	Size		(lbs)	weight	A	Dia. Hole	Thickness		F	ĸ	-			•		Maste 3 Par
1		50	200	23	3/4				20		24 ¹ / ₄			9 ³ / ₁₆		-
2	116 to 24	150	600	26	1	1	3⁄4	4 ¹ / ₂	20 ³ ⁄ ₄	5 ¹⁵ /16	25	71/8	1	9 ¹⁵ / ₁₆	11/4	ata
3	172 10 24	450	1,800	38					24 ¹ / ₈		28 ³ / ₈			13 ⁵ ⁄16		D
4		900	3,600	67	11/4				24 ⁵ ⁄16		295/8			12		
5	6 to 20	1,350	5,400	82	114	11/2	1 ½	65%	25 ¹³ / ₁₆	6 %16	31 1/⁄8	9 ¹ ⁄ ₄	11/2	131/2	1 ¹³ ⁄16	dex
6	0.030	1,800	7,200	98	172				27 ¹³ /16		33 ½			15½		

